

Acoustic Door Seal Kit Installation Instructions

Standard Size:

Treats 1 Standard Size Door



Included:

- (1) Roll of Acoustic Door Seal Tape - 3/16"x1/2"x25'
- (1) Roll of Acoustic Door Sweep Tape - 1/2"x1.5"x4'

Large Size:

Treats Up To 4 Standard Size Doors



Included:

- (2) Rolls of Acoustic Door Seal Tape - 3/16"x1/2"x50'
- (1) Roll of Acoustic Door Sweep Tape - 1/2"x1.5"x25'

Step 1: Make sure the door jamb and stop are clean of dust and dirt.



Step 2: On the hinge side of the door, measure for the height of the seal.



Step 2 Continued: Adhere the foam seal directly to the door jamb.




Trim to fit.



Step 2 Continued: Remove paper backing.



Step 3: On the top of the door, measure for the width of the seal.



Step 3 Continued: Adhere the foam seal to the upper door stop.



Trim to fit.



AUDIMUTE[™]
sound management solutions

Audimute.com
1.866.505.MUTE

Step 3 Continued: Remove paper backing.



Step 4: Repeat Step 3 for the handle side of the door. Measure for the height of the seal.



Step 4 Continued: Adhere the foam seal directly to the door stop. Trim to fit.



Remove paper backing.




Note: Use a flashlight to check for gaps on the side and top of the door.



If light gets through, consider adding another layer of seal.



Step 5: Make sure the bottom of your door is clean of any dust or dirt.





Measure for the width of the sweep.



Step 5 Continued: Adhere the foam sweep directly to the door.



It's best to attach the sweep to the side of the door where the noise is coming from.



Step 5 Continued: Trim to fit. Remove paper backing.

